

AirNet® II

2 Channel Particle Sensor

AVAILABLE WITH
ISO 17025
CALIBRATION
for select parameters



The Airnet II particle sensor makes it easy and cost-effective to monitor your cleanroom. This particle sensor offers a small footprint, unparalleled performance, and data transmission capabilities while meeting the specification of ISO 21501-4 and ISO 14644-1:2015.

Simple installation with versatile power options, the unit can be configured to accept distributed power from an in-house system, local power plug-in, or Power over Ethernet (PoE). Communication capabilities include Ethernet to interface with Pharmaceutical Net, Facility Net, or FacilityPro® software, OPC communications, Modbus communications, or optional 4-20 mA output.

Data integrity is maintained through the use of a data queue feature that continues to gather data even if network communication is lost.

To ensure proper flow conditions and vacuum system operation, these units incorporate a Dynamic Flow Sensing system that will alarm with a 15% change in flow conditions.

For applications where decontamination using Vaporized Hydrogen Peroxide (VHP) is required, an optional VHP-compatible unit is available for a simple installation without complex valving (AirNet 510XR).

BENEFITS

- Proven technology provides reliable and accurate data
- Allows for immediate reaction to particle contamination events
- A low-cost solution for multipoint monitoring
- Interfaces with Facility Net, Pharmaceutical Net and FacilityPro Software for comprehensive management of cleanroom conditions
- A small footprint and flexible mounting options make it easy to install in cleanrooms and mini-environments
- A laser diode (LD) drastically reduces the need for maintenance and extends product lifecycle
- Automatic laser shutdown reduces laser failures
- Data queue maintains data integrity when communication is lost
- Optional 4-20 mA output for integration with existing systems to help you understand your environment and communicate with other systems
- Optional XR coating protects sensors against corrosive or oxidizing vapors in VHP sterilization processes

FEATURES

- 2 channels
- 0.5 and 5.0 μm size range, suitable for Pharmaceutical application
- 1.0 CFM flow rate
- Interfaces with object linking and embedding (OLE) for process control (OPC) communications, Modbus communications and optional 4-20 mA output
- Chemical-resistant polycarbonate (PC) enclosure
- Low sample point cost
- Small enough for use in remote locations
- ISO14644-1:2015 Compliant

APPLICATIONS

- Cleanroom monitoring
- Dedicated monitoring of critical locations
- Trend analysis
- Statistical process control
- Multi-location monitoring
- Isolator monitoring



Without measurement there is no control

AirNet® II

2 Channel Particle Sensor

Specifications

	301	501/501A	510	510XR
Size Range	0.3, 0.5 µm	0.5, 5.0 µm ¹	0.5, 5.0 µm	0.5, 5.0
Flow Rate	0.1 CFM (2.8 LPM)	0.1 CFM (2.8 LPM)	1.0 CFM (28.3 LPM)	1.0 CFM (28.3 LPM)
Counting Efficiency	50% ± 20% for most-sensitive channel. Meets ISO 21501-4 100% ± 10% at 1.5 to 2.0 times channel one size. Meets ISO 21501-4			
Zero Count	≤ 70.7 counts/m ³	≤ 70.7 counts/m ³	≤ 7.07 counts/m ³	≤ 7.07 counts/m ³
Maximum Concentration²	5,695,168/ft ³	9,578,238/ft ³	957,824/ft ³	957,824/ft ³
Laser Source	Diode			
Laser Classification	Class 1 per EN60825 (Internally, a Class IIIB laser is used, per EN60825)			
Exterior Surface	Polycarbonate			
Dimensions (H x W x L)	5.3 x 3.6 x 3.8 in (13.5 x 8.9 x 9.6 cm)	5.3 x 3.6 x 3.8 in (13.5 x 8.9 x 9.6 cm)	5.3 x 3.6 x 3.8 in (13.5 x 8.9 x 9.6 cm)	5.3 x 3.6 x 3.8 in (13.5 x 8.9 x 9.6 cm)
Weight	1.6 lb (0.73 kg)	1.6 lb (0.73 kg)	1.6 lb (0.73 kg)	1.6 lb (0.73 kg)
Sample Probe or Tubing	1/4" ID	1/4" ID	1/4" ID	1/4" ID
Flow System	External vacuum 1/4" connection; automatic laser shutoff and alarm on 15% flow variation			
Vacuum Source	> 11 in Hg (> 375 mBar) below atm pressure	> 11 in Hg (> 375 mBar) below atm pressure	> 15 in Hg (> 410 mBar) below atm pressure	> 15 in Hg (> 410 mBar) below atm pressure
Power	24 VDC (0.5 A) 100 – 240 VAC ± 10%, 50 – 60 Hz, Power Supply (optional), or use of Power over Ethernet 48 VDC via a PoE router			
Communication Connectors	Ethernet (Particle Measuring Systems proprietary protocol, OPC, Modbus TCP) RS-232 (configuration and diagnostic tool only, no data) 4-20 mA (optional) (3 output channels: 2 particle data, 1 instrument status)			
Status Indicators	Programmable status (two-color LED), Activity (one-color LED)			
Calibration	Calibration materials used are traceable to the National Institute of Standards and Technology (NIST) and meet ISO 21501-4 requirements			
Environment	Temperature: 4 – 35 °C, 5 – 95%: non-condensing relative humidity			
Complies with	EU RoHS, ISO 21501-4, ISO 14644-1:2015			

¹ AirNet II 501A has 0.5 and 1.0 µm channels.

² 10% coincidence loss at maximum concentration.

Airnet®, FacilityPro® and IsoAir® are registered trademarks of Particle Measuring Systems, Inc. All other trademarks are the property of their respective owners. Particle Measuring Systems, Inc. reserves the right to change specifications without notice.

HEADQUARTERS

5475 Airport Blvd
Boulder, Colorado 80301 USA
T: +1 303 443 7100, +1 800 238 1801

Instrument Service & Support
E: +1 800 557 6363
Customer Response Center
T: +1 877 475 3317
E: info@pmeasuring.com

GLOBAL OFFICES

BRAZIL
T: +55 11 5188 8227
E: pmsbrazil@pmeasuring.com

CHINA
T: +86 21 6113 3600
E: pmschina@pmeasuring.com

FRANCE
T: +33 (0)6 82 99 17 98
E: pmsfrance@pmeasuring.com

GERMANY
T: +49 6151 6671 632
E: pmsgermany@pmeasuring.com

ITALY
T: +39 06 9053 0130
E: pmsr@pmeasuring.com

JAPAN
T: +81 3 5298 8175
E: pmsjapan@pmeasuring.com

KOREA
T: +82 31 286 5790
E: pmskorea@pmeasuring.com

MEXICO
T: +52 55 2271 5106
E: pmsmexico@pmeasuring.com

NORDIC
T: +45 707 028 55
E: pmsnordic@pmeasuring.com

PUERTO RICO
T: +1 787 718 9096
E: pmspuertorico@pmeasuring.com

SINGAPORE
T: +65 6496 0330
E: pmsingapore@pmeasuring.com

TAIWAN
T: 886-3-5525300 Ext: 301
E: pmstaiwan@pmeasuring.com

UNITED KINGDOM
T: +44 1684 581 000
E: pmsemea@pmeasuring.com

